

# Applicable Models of Cable Redundancy Function

Products with the Cable Redundancy function for NJ/NX-series are listed below.

| Product Name            | Model             | Version           |
|-------------------------|-------------------|-------------------|
| EtherCAT Junction Slave | GX-JC03           | Ver. 1.1 or later |
| EtherCAT Coupler Unit   | NX-ECC203         | Ver. 1.5 or later |
| EtherCAT Slave Unit     | CJ1W-ECT21        | Ver. 1.0 or later |
| Digital I/O Terminal    | GX-ID1611         | Ver. 1.2 or later |
|                         | GX-ID1621         | Ver. 1.2 or later |
|                         | GX-OD1611         | Ver. 1.2 or later |
|                         | GX-OD1621         | Ver. 1.2 or later |
|                         | GX-OC1601         | Ver. 1.2 or later |
|                         | GX-MD1611         | Ver. 1.2 or later |
|                         | GX-MD1621         | Ver. 1.2 or later |
|                         | GX-ID1612         | Ver. 1.2 or later |
|                         | GX-ID1622         | Ver. 1.2 or later |
|                         | GX-OD1612         | Ver. 1.2 or later |
|                         | GX-OD1622         | Ver. 1.2 or later |
|                         | GX-MD1612         | Ver. 1.2 or later |
|                         | GX-MD1622         | Ver. 1.2 or later |
|                         | GX-ID1618         | Ver. 1.2 or later |
|                         | GX-ID1628         | Ver. 1.2 or later |
|                         | GX-OD1618         | Ver. 1.2 or later |
|                         | GX-OD1628         | Ver. 1.2 or later |
|                         | GX-MD1618         | Ver. 1.2 or later |
|                         | GX-MD1628         | Ver. 1.2 or later |
|                         | GX-ID3218         | Ver. 1.2 or later |
|                         | GX-ID3228         | Ver. 1.2 or later |
|                         | GX-OD3218         | Ver. 1.2 or later |
|                         | GX-OD3228         | Ver. 1.2 or later |
|                         | GX-MD3218         | Ver. 1.2 or later |
| GX-MD3228               | Ver. 1.2 or later |                   |
| Analog I/O Terminal     | GX-AD0471         | Ver. 1.2 or later |
|                         | GX-DA0271         | Ver. 1.2 or later |
| IO-Link Master Unit     | GX-ILM08C         | Ver. 1.2 or later |
| Encoder Input Terminal  | GX-EC0211         | Ver. 1.2 or later |
|                         | GX-EC0241         | Ver. 1.2 or later |

(Continued on next page)

Note. For details, refer to the Data sheet or User's Manual of each products.

| Product Name    | Model            | Version          |
|-----------------|------------------|------------------|
| AC Servo System | R88D-1SAN02H-ECT | Ver.1.0 or later |
|                 | R88D-1SAN04H-ECT | Ver.1.0 or later |
|                 | R88D-1SAN08H-ECT | Ver.1.0 or later |
|                 | R88D-1SAN10F-ECT | Ver.1.0 or later |
|                 | R88D-1SAN10H-ECT | Ver.1.0 or later |
|                 | R88D-1SAN15F-ECT | Ver.1.0 or later |
|                 | R88D-1SAN15H-ECT | Ver.1.0 or later |
|                 | R88D-1SAN20F-ECT | Ver.1.0 or later |
|                 | R88D-1SAN20H-ECT | Ver.1.0 or later |
|                 | R88D-1SAN30F-ECT | Ver.1.0 or later |
|                 | R88D-1SAN30H-ECT | Ver.1.0 or later |
|                 | R88D-1SN01H-ECT  | Ver.1.4 or later |
|                 | R88D-1SN01L-ECT  | Ver.1.4 or later |
|                 | R88D-1SN02H-ECT  | Ver.1.4 or later |
|                 | R88D-1SN02L-ECT  | Ver.1.4 or later |
|                 | R88D-1SN04H-ECT  | Ver.1.4 or later |
|                 | R88D-1SN04L-ECT  | Ver.1.4 or later |
|                 | R88D-1SN06F-ECT  | Ver.1.4 or later |
|                 | R88D-1SN08H-ECT  | Ver.1.4 or later |
|                 | R88D-1SN10F-ECT  | Ver.1.4 or later |
|                 | R88D-1SN10H-ECT  | Ver.1.4 or later |
|                 | R88D-1SN15F-ECT  | Ver.1.4 or later |
|                 | R88D-1SN15H-ECT  | Ver.1.4 or later |
|                 | R88D-1SN20F-ECT  | Ver.1.4 or later |
|                 | R88D-1SN20H-ECT  | Ver.1.4 or later |
|                 | R88D-1SN30F-ECT  | Ver.1.4 or later |
|                 | R88D-1SN30H-ECT  | Ver.1.4 or later |
|                 | R88D-1SN150F-ECT | Ver.1.3 or later |
|                 | R88D-1SN150H-ECT | Ver.1.3 or later |
|                 | R88D-1SN55F-ECT  | Ver.1.3 or later |
|                 | R88D-1SN55H-ECT  | Ver.1.3 or later |
|                 | R88D-1SN75F-ECT  | Ver.1.3 or later |
|                 | R88D-1SN75H-ECT  | Ver.1.3 or later |

(Continued on next page)

Note. For details, refer to the Data sheet or User's Manual of each products.

| Product Name                               | Model        | Remarks   |
|--|--------------|---|
| High-function<br>General-purpose Inverters | 3G3RX2-A2004 | The optional<br>3G3AX-RX2-ECT<br>Communication<br>Unit is required for<br>EtherCAT<br>connection. |
|  | 3G3RX2-A2007 |   |
|  | 3G3RX2-A2015 |   |
|  | 3G3RX2-A2022 |   |
|  | 3G3RX2-A2037 |   |
|  | 3G3RX2-A2055 |   |
|  | 3G3RX2-A2075 |   |
|  | 3G3RX2-A2110 |   |
|  | 3G3RX2-A2150 |   |
|  | 3G3RX2-A2185 |   |
|  | 3G3RX2-A2220 |   |
|  | 3G3RX2-A2300 |   |
|  | 3G3RX2-A2370 |   |
|  | 3G3RX2-A2450 |   |
|  | 3G3RX2-A2550 |   |
|  | 3G3RX2-A4007 |   |
|  | 3G3RX2-A4015 |   |
|  | 3G3RX2-A4022 |   |
|  | 3G3RX2-A4037 |   |
|  | 3G3RX2-A4055 |   |
|  | 3G3RX2-A4075 |   |
|  | 3G3RX2-A4110 |   |
|  | 3G3RX2-A4150 |   |
|  | 3G3RX2-A4185 |   |
|  | 3G3RX2-A4220 |   |
|  | 3G3RX2-A4300 |   |
|  | 3G3RX2-A4370 |   |
|  | 3G3RX2-A4450 |   |
|  | 3G3RX2-A4550 |   |
|  | 3G3RX2-B4750 |   |
| 3G3RX2-B4900                               |              |   |
| 3G3RX2-B411K                               |              |   |
| 3G3RX2-B413K                               |              |   |

Note. For details, refer to the Data sheet or User's Manual of each products.

EtherCAT® is a registered trademark of Beckhoff Automation GmbH for their patented technology.  
Note: Do not use this document to operate the Unit.

**OMRON Corporation Industrial Automation Company**

Tokyo, JAPAN

Contact: [www.ia.omron.com](http://www.ia.omron.com)

**Regional Headquarters**

**OMRON EUROPE B.V.**

Wegalaan 67-69, 2132 JD Hoofddorp  
The Netherlands  
Tel: (31)2356-81-300/Fax: (31)2356-81-388

**OMRON ELECTRONICS LLC**

2895 Greenspoint Parkway, Suite 200  
Hoffman Estates, IL 60169 U.S.A  
Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

**OMRON ASIA PACIFIC PTE. LTD.**

No. 438A Alexandra Road # 05-05/08 (Lobby 2),  
Alexandra Technopark,  
Singapore 119967  
Tel: (65) 6835-3011/Fax: (65) 6835-2711

**OMRON (CHINA) CO., LTD.**

Room 2211, Bank of China Tower,  
200 Yin Cheng Zhong Road,  
PuDong New Area, Shanghai, 200120, China  
Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

**Authorized Distributor:**

© OMRON Corporation 2021 All Rights Reserved.  
In the interest of product improvement,  
specifications are subject to change without notice.

**Cat. No. R200-E1-04**

1021 (0619)